



# CANAL TOYS STYLE 4 EVER

## BAT - OFG 267 - LIGHT UP MINI DECO DIY - FOB\_4 MANUAL - A6 - NOIR & BLANC

**ŚWIECĄCE DEKOROŻCE** 6+

**ZWIERZĄCZKI DIY**

**MINI DECO DIY**

**ZAWARTOŚĆ CONTENTS**

- 1 figurka Dekorożca
- 1 character
- 1 arkusz naklejek
- 1 sticker sheet
- 1 pisak
- 1 marker

**Montaż i wymiana baterii – Adding batteries**

ZAMKNIĘTE CLOSED    OTWARTE OPEN

Produkt wymaga 3 baterii LR1130 1,5V (zawarte w zestawie).  
Needs 3 batteries 1,5V LR1130 (included).

©2023 Canal Toys®  
Zaprojektowano we Francji • Designed in France  
Wyprodukowano w Chinach • Made in China

**OSTRZEŻENIE!** Nieodpowiednie dla dzieci w wieku poniżej 3 lat, ze względu na drobne elementy łatwe do połknięcia – ryzyko udławienia. W przypadku połknięcia niezwłocznie skontaktować się z lekarzem. Po użyciu produktu dokładnie umyć ręce! Trzymaj z dala od ust i oczu. Nie rysuj dołączonym do zestawu pisakiem po skórze. Należy zachować opakowanie, etykiety lub ulotki, na których zamieszczone są informacje o zabawce. Przed podaniem zabawki dziecku należy usunąć opakowanie i wszystkie plastikowe zaczepy. Kolory i kształty mogą się nieznacznie różnić od tych pokazanych na opakowaniu.

**BATERIE: Montaż i wymiana.** Produkt wymaga 3 baterii LR1130 1,5V (zawarte w zestawie). Aby wymienić baterie, ustaw przełącznik na pozycję OFF. Otwórz za pomocą śrubokręta pokrywę komory na baterie, znajdującą się na spodzie zabawki i włóż do środka nowe baterie. Upewnij się, że baterie zostały włożone zgodnie z zaprezentowaną polaryzacją. Następnie, dla bezpieczeństwa dziecka, przykręć z powrotem pokrywę baterii.

**UWAGA:** Ze względu na małe części, zaleca się instalowanie i wymianę baterii wyłącznie przez osoby dorosłe. Nie należy mieszać baterii różnego typu, np. jednorazowych i baterii do ponownego ładowania, a także baterii nowych z używanymi. Baterie muszą być włożone zgodnie z polaryzacją (+/-) zaprezentowaną w komorze na baterie. Jeśli zabawka jest nieużywana przez dłuższy czas lub baterie się wyczerpały, należy je niezwłocznie usunąć, aby nie uszkodziły zabawki. Nie należy ładować baterii, które nie są do tego przeznaczone. Baterie przed ponownym ładowaniem należy bezwzględnie usunąć z zabawki. Demontaż i ładowanie baterii powinny być wykonane przez osobę dorosłą lub pod nadzorem osoby dorosłej. Nie wolno dopuścić do zwarcia na zaciskach. Nie rob śpięcia. Nie należy zasilać zabawki za pomocą innych źródeł energii niż baterie alkaliczne. Zużyte baterie należy wyrzucić do specjalnie oznakowanego pojemnika. Nie wrzucać baterii do ognia, mogą eksplodować lub wydeć. Przed każdym użyciem należy sprawdzić czy produkt nie nosi śladów uszkodzenia elementów elektrycznych. W razie usterki, nie używać go do czasu naprawy.

Ne likwidować ze stałymi odpadami mieszkimi, lecz zbierać oddzielnie. Porzucenie lub niewłaściwe stosowanie substancji lub komponentów elektrycznych, które znajdują się w tym aparacie, może okazać się szkodliwe dla środowiska. Symbol, na którym widnieje „pojemnik na śmieci na kółkach, z czarną kreską u dołu” oznacza, że niniejszy aparat został wprowadzony do handlu po 13/08/05 r. i podlega obowiązkowi różnicowanego zbierania odpadów. Wszelkie nadużycia będą karane według prawa.

**WARNINGS!** Not suitable for children under 36 months. Small parts. Choking hazard. Remove all elements and packaging parts before giving the toy to your child (example: plastic clips). Wash hands after use! Keep away from mouth and eyes. Non contractual pictures. The colors of the contents and the details may change. Please keep all the relevant information for future reference. For customer service in Great Britain, contact Canal Toys Distribution Ltd, Regency House, York Business Park, York, YO26 6RW, Great Britain or email to: enquiries@canaltoys.uk

**OPERATION WITH BATTERIES: Replacement and installation.** This product requires 3 batteries 1,5V LR1130 (included). Firstly, set the switch to the OFF position. Remove the safety screw from the lid of the battery compartment located at the bottom of the base. Remove the dead batteries. Notice that the correct placement of the batteries in the image and place them according to the position and polarity indicated. Finally, replace the lid and the safety screw (for your children's safety).

**CAUTION:** - Dispose of used batteries immediately. - Keep new and used batteries out of the reach of children. - If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention. - Batteries are to be inserted with the correct polarity. - Only batteries of the size and type indicated are to be used. - Do not mix standard and rechargeable batteries. - Do not mix old and new batteries. - Exhausted batteries are to be removed from the toy. - Non-rechargeable batteries are not to be recharged. - Rechargeable batteries are only to be charged under adult supervision. - Rechargeable batteries are to be removed from the toy before being charged. - The supply terminals are not to be short-circuited. - Do not dispose of batteries in re. They may leak or explode. - Do not throw batteries away but dispose of as household chemical waste. Please use the local recycling collection points provided.

The wheellie bin symbol with a cross indicates that the product must not be disposed of in the domestic waste at the end of its useful life. Instead, it should be taken to your nearest designated collection point or recycling facility. Alternatively, (a) check with your retailer and return the product when buying a replacement, on a one-to-one basis pursuant to article 5, comma b, (b) disposal free of charge with no obligation to purchase for small-sized WEEE (external dimension below 25 cm in retail stores with a sales area of EEE of at least 400m2) pursuant to Article 5, comma c. Appropriate disposal promotes the recycling of parts and materials, as well as helping to protect the environment and human health. Under current legislation, strict penalties are enforced against those disposing of products illegally. For more information about the collection of special waste, contact your Local Authority.

EP60040

Producent / Manufacturer: Canal Toys, 18, rue Cumonsky, 75017 PARIS, FRANCE  
Regency House, York Business Park, York, YO26 6RW, GREAT BRITAIN

Importer / Dystrybutor: Epee Polska Sp. z o.o., al. Bohaterów Warszawy 15-16, 70-370 Szczecin, www.epee.pl

**OSTRZEŻENIE WARNING!**

0-3

A Canal Toys® Brand.

SHARE AND FOLLOW US!  
www.canaltoys.com